

# Keep it **clean.**

Simple ways to keep your **Height-AdjustTable** or **Walkstation** nearly as clean as the day it was first installed.

## **Paints and Plastics**

For painted metals and plastics - ordinary dirt, smudges and water soluble stains can be removed with mild soap and water. If needed for difficult stains, use a hardsurface, all-purpose cleaner such as Formula 409® or Fantastik®. Some oil-borne stains may require the use of a solvent based cleaner, which should always be tested in a hidden location prior to general use.

## **Worksurfaces**

Wiping with a damp cloth will remove general soiling and water-borne stains. If needed, use a hard-surface, all purpose cleaner such as Formula 409® or Fantastik®. Follow the manufacturer's instructions for general purpose cleaning. To prevent staining, ink should be removed as soon as possible.

To fill scratches in wood grain laminate tops, use an oak, walnut, or mahogany putty stick which can be purchased at paint supply and hardware stores.



## Care and Cleaning instructions for Urethane Profile

Urethane profile edges are generally stain resistant to most compounds or staining agents found in the office, food and health care industries. Most food condiments such as ketchup, mustard, steak sauce, etc will clean up easily. However, bacteriostatic agents such as *Iodine* and *Betadine* have the greatest staining potential and care should be exercised to avoid exposing this product to these as such stains can usually be only partially removed.

When cleaning, avoid using harsh cleaners with abrasive additives. Never attempt to use sharp metal objects or sandpaper to remove stains. Do not use bleach to clean the edge. Do not use hard bristle brushes. All of these will cause permanent damage to the edge and laminate worksurface and will void the warranty.

Ordinary soiled edges caused by normal use can be cleaned with a damp cloth or sponge and *Clorox® Clean-Up® Cleaner with Bleach* or *Formula 409®*. For stains, if a scrub brush is used, make sure it is a soft bristle type to prevent scratching. Successive cleanings may be required using a soft bristle brush and 70% Isopropyl Alcohol.



**Urethane Profile Worksurface:** has 90° corners. Front (user's) edge has the urethane profile only. Back and side edges are flat. When specifying a Urethane Profile worksurface, please choose a finish: Black or Felt.

For a better day at work.™

**details®**

A STEELCASE COMPANY

P.O. Box 1967 / CD-5E / Grand Rapids, MI 49501-1967 / [www.details-worktools.com](http://www.details-worktools.com)

©2007 Office Details Inc. All rights reserved. 12/07

# Keep it **clean.**

Simple ways to keep your **Height-AdjustTable** or **Walkstation** nearly as clean as the day it was first installed.

Your treadmill is constructed of quality materials and manufactured to provide many years of faithful service. Simple routine cleaning and a preventive maintenance program will extend the life of your treadmill.

**To prevent electrical shock, be certain the treadmill is turned off and unplugged from the electrical outlet before performing any cleaning or routine maintenance.**

## Regular Cleaning

**Important:** do not clean or wipe under the running belt.

**Daily:** Perspiration should be wiped from the control console and treadmill surfaces after use.

**Weekly:** Wipe down your treadmill once a week with a water dampened, soft cloth. Be careful not to get excessive moisture between the edge of the overlay panel and the console, as this might create an electrical hazard or cause the electronics to fail.

**Monthly:** Clean dust and dirt under and behind your treadmill once a month. Small rubber particles from the soles of walking shoes will accumulate alongside the belt and also behind the unit.

**Expert Service:** Expert service and maintenance at a reasonable cost are available through a factory-trained, authorized dealer. The dealer maintains a stock of repair and replacement parts and has the technical knowledge to meet your service needs.



For a better day at work.™

**details**®

A STEELCASE COMPANY

P.O. Box 1967 / CD-5E / Grand Rapids, MI 49501-1967 / [www.details-worktools.com](http://www.details-worktools.com)

©2007 Office Details Inc. All rights reserved. 12/07